



# HOW TO USE THE VIEW-MASTER FILM INSERTER

## 1. Place Film Between the Blades

To avoid fingerprints, pick up film with the Film Inserter.

Film should be emulsion (dull) side up. The short, square blade of the Film Inserter should be up.



## 2. Insert Film and Both Blades Into the Reel Pocket

The long blade will slip outside the inner edge of the pocket while the short blade will stop just short of the inner edge when the film is properly seated.

Then, withdraw the Film Inserter leaving the film in place.

**IMPORTANT!** Use Film Inserter to remove film from Reels. Slip Film Inserter into pocket, long blade under and short blade over the film. Press blades firmly together in the Reel window and withdraw film until it can be grasped from outside the Reel.

Friendly stereoscopic greetings from your worldwide 3D supplier

[WWW.3DWORLDSHOP.COM](http://WWW.3DWORLDSHOP.COM)

Check out our webshop for 3D products & services!

Also check out our 3D Photo Archive:

<http://3dstereo.jalbum.net>